


Aimpoint®


Acro™ mount for Blaser rifles Setup guide



1



2



MAX. 3 Nm / 2.2 ft·lb

DO NOT OVERTIGHTEN!

NICHT ZU STARK ANZIEHEN!


NE PAS SERRER TROP FORT!

NO EXCEDERSE AL APRETAR!


NON STRINGERE ECCESSIVAMENTE!

DRA INTE ÅT FÖR HÅRT!


3



4




5



**TOO LOOSE?
ZU LOCKER?
TROP DESSERRE?
DEMASIADO FLOJO?
TROPPO ALLENTATO?
FÖR LÖS?**



6



MAX. 1.5 Nm / 1.1 ft·lb

DO NOT OVERTIGHTEN!

NICHT ZU STARK ANZIEHEN!

NE PAS SERRER TROP FORT!

NO EXCEDERSE AL APRETAR!

NON STRINGERE ECCESSIVAMENTE!

DRA INTE ÅT FÖR HÅRT!



Aimpoint AB

Jägershillgatan 15
SE- 213 75 Malmö, Sweden
Phone: +46 (0)40 671 50 20
Fax: +46 (0)40 21 92 38
e-mail: info@aimpoint.se

Aimpoint Inc.

7309 Gateway Court
Manassas, VA 20109, USA
Phone: +1 703-263-9795
Fax: +1 703-263-9463
e-mail: info@aimpoint.com

WWW.AIMPOINT.COM

© 2022 Aimpoint AB. [16891-1]

